

Service & Maintenance

Our SERVICE

- ▲ Visual inspection
- ▲ Disassembly and cleaning
- ▲ Analysis of the current state
- ▲ Replacement of all sealing elements
- ▲ Assembly, functional testing and creation of a test log
- ▲ In the event that repairs are necessary, we will create a fair offer with a binding delivery date




Maintenance recommendations

Precision tools are often subject to difficult operating conditions in the machining process, where swarf, dirt, cooling lubricants and mechanical stresses lead to high levels of wear, compromising the quality of the finished end product and often causing reduced process capacity.

Regular maintenance prevents expensive repairs. Planning maintenance at an early stage significantly reduces the risk of machine downtimes.

Conclusion: Regular maintenance increases the service life of actuating tools and the costeffectiveness of the system as a whole.



An initial assessment is carried out at a set time. An individual maintenance plan will be developed on the basis of the operating conditions.

Maintenance intervals

These guideline values may vary depending on the specific application.

Lubrication	Maintenance intervals
Permanent	2000 – 3000 operating hours at least every 1 – 2 years
Central, automatic lubrication cycle	8000 – 10000 operating hours 7 million strokes
Manual	3000 – 4000 operating hours
Manual	3000 – 4000 operating hours
	Permanent Central, automatic lubrication cycle Manual

And if repairs do become necessary: No problem.

Repair or maintenance work on head and base elements should only be repaired or serviced at the CERATIZIT location in Besigheim, Germany. All actuating tools are in a mechanically perfect condition when they leave our assembly department. In order to prevent production downtimes, we recommend procurement of a replacement tool.



KOMET KOMlife maintenance system –
Autonomous acquisition of production data accurate to the second

The operating data will be provided via dynamic QR Code. It can be used on various systems.

