

# SELECTION

HardCut

**Hard turning with  
PCBN indexable inserts**

CERATIZIT is a high-technology engineering group specialised in cutting tools and hard material solutions.

**Tooling a Sustainable Future**

[www.ceratizit.com](http://www.ceratizit.com)



# Welcome!



It couldn't be easier

## Ordering via the Online Shop

<http://cuttingtools.ceratizit.com>



On-site technical support

## Your Local Technical Sales Engineer

Your customer number

# Tooling a Sustainable Future

CERATIZIT: a specialist in sustainable cutting tools and hard material solutions.

Are you looking for a reliable partner for your tooling and machining-process needs? Then look no further! CERATIZIT is not just a tool supplier. Our experts are also on hand to advise you with extensive industry knowledge and decades of experience.

What's more, anyone who wants to pay particular attention to their CO2 balance, will find in us a sustainability-conscious partner with a concrete strategy and target set out in our vision of becoming the number 1 sustainable company in our industry.

For more than 100 years, CERATIZIT has been a pioneer in the field of ambitious hard material solutions for machining and protection against wear. This allows us to guarantee our customers the highest levels of quality and access to the latest developments in the carbide sector – all-round cutting tools expertise from a single source.



**30** production sites



**80** countries in which we are active



**1 000** patents and utility models


# Editorial

Dear customers,

Extremely hard cutting materials allow you to machine hardened cast iron materials (hardness >55 HRC) with geometrically defined cutting edges. At the top end of the cutting material hardness scale are polycrystalline diamonds and cubic boron nitride, which is usually the first choice for hard machining. As your partner for premium-class machining solutions, who guarantees maximum tool life and optimal process security, we offer a wide range of PCBN cutting materials. Take a look at our portfolio of PCBN indexable inserts. Use our selection to find out more about hard machining and about the PCBN indexable inserts which are used in this area. Benefit from our application recommendations and use our tips to see for yourself what our PCBN cutting materials can do, and optimise your process.


Should you have any questions, our specialists in hard machining will be happy to help.

Your CERATIZIT team



## Cutting material – hardness comparison

PCBN is one of the hardest materials in the world. In addition to many other exceptional properties, it is this hardness which makes the material ideal for machining hard, abrasive components. PCBN has a greater chemical and thermal stability than diamond, which reacts with iron and has a maximum temperature limit of approx. 700°C (1300°F). PCBN is resistant up to temperatures exceeding 1000°C (1800°F) and is therefore ideal for the high machining temperatures when hard turning.



## Table of contents

### Introduction

Toolfinder – indexable inserts	6+7
Toolfinder – holders	8+9
Introduction to hard turning	10–18
<b>Cutting edge preparation</b>	<b>19</b>
<b>Grade description</b>	<b>20</b>
<b>Selecting the correct PCBN indexable insert</b>	<b>21</b>
<b>Product programme</b>	<b>22–45</b>
<b>Cutting Data</b>	<b>46–49</b>

### Technical Information


Wet or dry machining	50
Advantages of hard turning over grinding	50
Impact of wear	51
Coating	52
Surface quality	53
Single-cut or dual-cut machining	54
ISO designation system	56–61
Types of wear	62
Measures in the case of problems	63+64
General formulae	65
Hardness comparison table	66
Material examples	67–69
<b>Project engineering</b>	<b>70–73</b>

## CERATIZIT \ Performance


Premium quality tools for high performance.

The premium quality tools from the **CERATIZIT Performance** product line have been designed for specific applications and are distinguished by their outstanding performance. If you make high demands on the performance of your production and want to achieve the very best results, we recommend the Premium tools in this product line.

## Toolfinder – indexable inserts




## PCBN grade key CERATIZIT




## Symbol explanation

**CTBH2000C** PCBN grade



A detailed grades overview can be found on → [Page 20](#)



## Toolfinder – holders

### Tool holders and boring bars for negative inserts

can be found in the **2023 main catalogue – Chapter 9, Indexable insert turning tools** on the following pages:



Geometry				
----------	--	--	--	--



→ 09 | 17–20

→ 09 | 23+24

→ 09 | 21

→ 09 | 22



→ 09 | 30–33

→ 09 | 40+41

→ 09 | 33–35

→ 09 | 36–39



→ 09 | 45–50

→ 09 | 51

→ 09 | 50



→ 09 | 55–57

→ 09 | 58



→ 09 | 61

→ 09 | 62

→ 09 | 62+63



→ 09 | 67+68

→ 09 | 70+71

→ 09 | 69

→ 09 | 69

### Tool holders and boring bars for positive inserts

can be found in the **2023 main catalogue – Chapter 9, Indexable insert turning tools** on the following pages:



Geometry				
----------	--	--	--	--



→ 09 | 81–87

→ 09 | 90–94

→ 09 | 88

→ 09 | 89



→ 09 | 104–110

→ 09 | 114–118

→ 09 | 111

→ 09 | 112+113



→ 09 | 143–146

→ 09 | 147



→ 09 | 154–162

→ 09 | 166–168

→ 09 | 162–164

→ 09 | 164+165

## Toolfinder – holders

### Exchangeable cutting heads and base holders for negative inserts

can be found in the **2023 main catalogue – Chapter 9, Indexable insert turning tools** on the following pages:



Geometry	Exchangeable cutting heads	cylindrical	HSK-T	PSC
	→ 09   178		→ 09   174	→ 09   171
	→ 09   178+179	→ 09   177	Vibration damped → 09   175	Vibration damped → 09   172
	→ 09   179		Actively vibration-damped → 09   176	Actively vibration-damped → 09   173

### Exchangeable cutting heads and base holders for positive inserts

can be found in the **2023 main catalogue – Chapter 9, Indexable insert turning tools** on the following pages:



Geometry	Exchangeable cutting heads	cylindrical	HSK-T	PSC
	→ 09   180		→ 09   174	→ 09   171
	→ 09   180+181	→ 09   177	Vibration damped → 09   175	Vibration damped → 09   172

# Introduction to hard turning

## Hard materials

The materials machined have a hardness of up to 67 HRC. Case-hardened steels are subject to soft pre-machining (unhardened) using carbide indexable inserts. After hardening (minimum hardness of steel 55 HRC) areas showing hardening distortions and also the running surfaces must be reworked.

When finish machining with PCBN, very high surface quality (up to  $R_a$  0.2) and close tolerances can be achieved. In many cases, grinding is not necessary.

## Turning instead of grinding

### Advantage/benefit

- ▲ Change to a grinding machine is not necessary
- ▲ Faster cycle time
- ▲ Several machining operations can be carried out with one tool: longitudinal and face turning, external and internal machining in one set-up
- ▲ Roughing and finishing in one process
- ▲ Coolant substitution


## Principle of hard turning

### Chip formation when machining steel

The softening of the chip thanks to high cutting speeds is the basis of hard machining. Shear chips can be created on hardened steel as a result of the cutting energy introduced (high temperatures). Carbide indexable inserts have a higher flexural strength than PCBN and are therefore more suitable for soft machining. From a hardness of 50 HRC, the temperatures generated during the machining process are so high that the wear of the carbide indexable insert is uneconomically high. The reason for this is the insufficiently elevated-temperature hardness of the carbide. In contrast, PCBN has a higher hardness than carbide and can still be used cost-effectively at high temperatures.


#### Example:

Material:	100Cr6 (1.1645)
Feed:	$f = 0.1 \text{ mm/rev}$
Cutting speed:	$v_c = 120 \text{ m/min}$



## Segmented chip with chip thickness $h_m > 0.02 \text{ mm}$

Due to the reduced width of cut of  $h_m > 0.02 \text{ mm}$ , the material (chip) is cut out upwards, the individual chip segments remain stuck to one another, thus forming the typical saw tip structure.





Material: 100Cr6 (60-62 HRC)  
Chip thickness:  $h_m = 0.05 \text{ mm}$

Crack on the surface of the steel

Chip segment is cut out, a new crack is created  
Chip segments fuse into one segmented chip

## Continuous chip with small chip thickness $h_m < 0.02 \text{ mm}$

As a result of the reduced width of cut  $h_m < 0.02 \text{ mm}$ , a continuous chip is created since the typical cracks are not created at this width of cut. The chip is evacuated across the tool cutting edge, so that there is no breakage and a continuous chip forms.



Material: 100Cr6 (60-62 HRC)  
Chip thickness:  $h_m = 0.005 \text{ mm}$

## Application

- ▲ The basis for hard machining is the softening of the chip as a result of the high cutting speeds  
→ Ideally, the chip is red hot.  
This can be recognised by the medium-grey tempering colour on the cooled-down back of the chip.

Under optimal processing conditions the resulting shear chip is brittle and can easily be crumbled between the fingers.

## CERATIZIT – the carbide concept for success


Carbide has become indispensable in numerous industries and production processes. Complex products and modern materials place increasingly high demand on tools, materials and precision processing.

Carbides are composite materials consisting of a hard material and a very tough binder metal. They are extremely hard, and are characterised by high wear resistance and high hot hardness. Carbide is used in various fields that require tools or components to be particularly wear-resistant, such as in the machining of hard materials. CERATIZIT composite carbides improve the quality of tools and components, give them a longer service life, reduce costs and ensure process reliability.

Carbides from CERATIZIT are made of super-strong tungsten carbide and a relatively soft binder metal such as cobalt. The two materials are fused in powder form. CERATIZIT offers more than 100 different carbide grades with different compositions. We have the perfect


solution for every application and industry. CERATIZIT masters the whole production process chain from powder production, moulding and sintering to finishing and surface treatment. We grind, polish or erode the blank and coat it with innovative wear-resistant coatings. This gives our product the properties required for industrial applications.

To make a finished carbide blank from a powder mix, you first need to press it into a mould. The resulting green compact can then be machined. Once it has been sintered at a temperature of between 1,300 and 1,500 degrees Celsius and a pressure of up to 100 bar, it is turned into a homogeneous and dense cutting material.




## Carbide – composite material with valuable properties

The amount of metal binder used and the grain size of the tungsten carbide both have an impact on the performance characteristics of the carbide. The specific composition determines the hardness, flexural strength and fracture toughness of the cutting material. The tungsten carbide grains have an average size of 0.5 to 20 micrometres ( $\mu\text{m}$ ). The softer binder metal, cobalt, fills the space in between.



On the one hand, when extremely high toughness is required, the cobalt content can amount to as much as 30%. On the other, the cobalt content is reduced and the grain size decreased to the ultrafine range (e.g. 0.3  $\mu\text{m}$ ), in order to guarantee maximum wear resistance.

CERATIZIT offers a customised solution for every one of your applications, particularly for the machining sector and wear parts.



### Grinding

- ▲ Peripheral grinding and chamfering; the indexable insert is ready for use

### Coating

- ▲ Coating using the PVD process, metals such as titanium and aluminium are heated under vacuum, vaporous and using electric voltage, they stick to the surface of the indexable insert.

### Quality assurance

- ▲ All products are subject to strict quality control tests by experienced specialists

### Delivery/dispatch

- ▲ Automated high-tech shuttle warehouse, ensuring that your goods are ready for dispatch in next to no time.

### Recycling

- ▲ We organise the entire process for you and also provide free collection containers.

## PCBN – production of round blanks

### Pyrolysis

of boron-halogen compounds  
in a catalytic reaction




Boron nitride with a hexagonal lattice structure



### PCBN – synthesis

Pressure: 5 – 9 GPa  
Temperature: 1600 – 2100°C



Boron nitride grains (grit) with cubic body and centred lattice

High hot hardness

Hardness at 800°C  
comparable with the  
hardness of carbide at  
room temperature

## PCBN – production of indexable inserts

### Round blank


Ø 40 - 100 mm




### Separating the tips

Laser or wire erosion  
process

### Brazing




#### Brazing under vacuum



Brazing temperature: approx. 900°C

#### Brazing under atmospheric pressure



Brazing temperature: approx. 750°C

→ **Hot pressing**  
of the PCBN grains

→ **PCBN round blanks**

Binder  
▲ Ceramic (TiC, TiN, TiCN, Al<sub>2</sub>O<sub>3</sub>)  
▲ Metallic (WC-Co-Ni)

Pressure: approx. 5 GPa  
Temperature: > 1000 °C



*Base body*  
flat cylindrical carbide substrate


## Properties of PCBN

- ▲ Second hardest cutting material after diamond (4,700 N/mm<sup>2</sup>)
- ▲ High wear resistance (abrasion)
- ▲ High oxidation resistance up to 1,250°C  
→ therefore suitable for the machining of iron alloys
- ▲ High compressive strength but low tensile strength
- ▲ Good thermal conductivity

→ **Grinding, chamfering, honing**  
(coating when necessary)

→ **End product**  
Ready-to-use indexable insert


### PCBN-tipped inserts



### Solid PCBN inserts



### Solid PCBN inserts with C-Clamp clamping dimple



### Solid PCBN inserts with hole



## Requirements of the machine, clamping, workpiece

### Stable machine


- ▲ Robust machine design, ideally specifically a machine for hard turning
- ▲ Extensive stress can lead to unstable processes on unstable machines

### Backlash-free guides

- ▲ Spindle run-out <0.7 µm
- ▲ Repeatability of the axes <0.8 µm
- ▲ Hydrostatic bearings
- ▲ Good maintenance condition of the machine
- ▲ Can cause the indexable insert to break uncontrollably, hindering the dimensional accuracy of the workpiece

### Steady rest and tailstock

- ▲ Absolutely necessary for long or thin-walled workpieces
- ▲ If the required surface quality cannot be achieved



### Tool interface

- ▲ Stable tool interface, avoid unnecessary overhangs
- ▲ Select the greatest possible tool interface
- ▲ Clamp the tool as short as possible



### Natural vibrations of the machine

- ▲ Stable machine foundation
- ▲ To counteract vibrations from other machines
- ▲ It is best for the machine to be on an encapsulated foundation




## Clamping and workpiece

### Clamping

#### One-sided clamped workpieces

- ▲ Clamp workpiece as short as possible, observe length and diameter ratio approx. 2:1
- ▲ Can lead to vibrations in the process



#### Long thin-walled workpieces

- ▲ Support workpieces with steady rest or tailstock
- ▲ To counteract vibrations in the process



#### Soft moulded jaws or collet

- ▲ Positive clamping of the workpiece/in particular for thin-walled workpieces
- ▲ Stable manufacturing process



### Workpiece pre-machining/soft machining

#### Burr formation

- ▲ Uncontrolled tool breakage when hard machining



#### Define tight dimension tolerances for pre-machining

- ▲ Better defined tool life when hard machining

#### Chamfers and radii

- ▲ Ensure a smooth entry and exit of the tool



#### Sharp edges


- ▲ Leads to edge breakages on cutting edge and workpiece

## Material effect on hard machining

### Hard machining with PCBN



When machining hardened steel, this is usually called hard machining. This machining mechanism involves self-induced hot machining. Here, a defined high temperature of approx. 550 to 750°C is needed in the shear zone. This required temperature is obtained by converting the existing energy into heat. This energy is available in the form of cutting speed  $v_c$ , feed  $f$ , depth of cut  $a_p$  and the chamfer geometries F-M-R of the PCD cutting edges. Cooling is usually not necessary. Below are three tempering diagrams. You can see the drop in hardness as the temperature increases.

There are however significant differences here. For self-induced hot machining with our PCD grades, the ideal hardness is in the shear zone at 40 to 45 HRC. This means that different machining temperatures between 550 to 750°C are required.



Hardening temperatures:

- At 980°C
- At 1020°C
- At 1050°C



At approx. 600°C, steel 1.2379 still has a hardness of approx. 58 HRC, steel 1.7131 of approx. 48 HRC and steel 1.3505 only achieves approx. 36 HRC, whereby the original hardness is approx. 62 HRC.

## Cutting edge preparation

The stability of a cutting edge increases as the chamfer angle and chamfer width increase, but at the same time the cutting force increases and subsequently also the temperature in the process. A larger chamfer distributes the cutting force across a larger area of the cutting edge. This increases the stability of the cutting edge, thereby facilitating higher feeds. If process stability and a constant tool life are the highest priority, then we recommend choosing a large chamfer. If the highest priority is to achieve a very good


surface quality and optimum dimensional accuracy, then it is advisable to use a small chamfer for the manufacturing process. Vibrations, cutting forces and temperature are hereby reduced. Hard turning in most cases is the finishing of the workpiece, the optimum cutting edge preparation is a deciding factor in order to reliably produce high-quality components with a long service life.

In the case of indexable inserts with no chip breaker, the correct chamfer design is vital, as well as the type of cutting edge. For this reason, the designation system has been extended with the following key to the various chamfer designs. The design and angle can be seen in the overview below.


### Preparation key at CERATIZIT

Designation in line with ISO Type of cutting edge	CERATIZIT chamfer design	Definition
<b>SN</b> (chamfered and rounded)	014D	0,14 x 20°
<b>EN</b> (rounded)	rounded	

Chamfer design **SN**



Chamfer width



Chamfer angle

Type of cutting edge **EN**



#### CODE FOR CHAMFER ANGLE GB

A	B	C	D	E	F	G
5°	10°	15°	20°	25°	30°	35°

Precision and geometrical accuracy

Process stability, tool life

Examples	Chamfer width [mm]	Chamfer angle GB
CNGA 120408SN-009C	0,09	15°
DCGW 11T304SN-014D	0,14	20°

## Grade description

### PCBN grade

### Features

#### CTBH1000C

ISO | H10

**Specifications:**


Composition: Cubic boron nitride (PCBN) 70% | binder phase ceramic | Grain size: 3 µm | Layer system: PVD TiN/TiAlN

**Recommended use:**

High-performance grade for hard turning in a smooth and slightly interrupted cut. Ideal for extremely worn and hardened steel grades.

#### CTBH2000C

ISO | H20

**Specifications:**

Composition: Cubic boron nitride (PCBN) 40% | binder phase ceramic | Grain size: 1 µm | Layer system: PVD TiN/TiAlN

**Recommended use:**

Excellent surface qualities. First choice for hard-soft machining and surface layer. Perfect for very small-scale production and use in a wide variety of applications.

#### CTBH3000C

ISO | H30

**Specifications:**


Composition: Cubic boron nitride (PCBN) 65% | binder phase ceramic | Grain size: 2-3 µm | Layer system: PVD TiN/TiAlN

**Recommended use:**

Particularly suitable for strong to slightly interrupted cuts. Can also be used in unfavourable machining conditions such as vibrations.

## Selecting the correct PCBN indexable insert


Machining	Smooth cut	Continuous to slightly interrupted cut	Strong to slightly interrupted cut
Interrupted cut			
Fine machining	CTBH1000C <b>F</b> EN rounded	CTBH2000C <b>F</b> EN rounded	CTBH3000C <b>F</b> 0,14mm x 20°
Medium machining	CTBH1000C <b>M</b> 0,09mm x 15°	CTBH2000C <b>M</b> 0,09mm x 15°	CTBH3000C <b>M</b> 0,18mm x 25°
Rough machining	CTBH1000C <b>R</b> 0,14mm x 20°	CTBH2000C <b>R</b> 0,14mm x 20°	CTBH3000C <b>R</b> 0,20mm x 35°





Interrupted cut	● ● ●	● ● ●	● ● ●
Cutting speed	● ● ●	● ● ●	● ● ●
Requirements on toughness	● ● ●	● ● ●	● ● ●

**CNGA**

Designation	L mm	S mm	D1 mm	IC mm
CNGA 1204..	12,9	4,76	5,13	12,7

**CNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners



71 003 ... 71 003 ... 71 003 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
120404EN	0,4			B (2)	3,3
120404SN	0,4	0,14	20°	B (2)	3,3
120408EN	0,8			B (2)	3,3
120408SN	0,8	0,14	20°	B (2)	3,3
120412EN	1,2			B (2)	3,1
120412SN	1,2	0,14	20°	B (2)	3,1

70002 80002 90002


70302 80302 90302

70602 80602 90602

P				
M				
K				
N				
S				
H			•	•
O			•	•

## CNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners




**71 003 ...** **71 003 ...** **71 003 ...**

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
120404SN	0,4	0,09	15°	B (2)	3,3
120404SN	0,4	0,18	25°	B (2)	3,3
120408SN	0,8	0,09	15°	B (2)	3,3
120408SN	0,8	0,18	25°	B (2)	3,3
120412SN	1,2	0,09	15°	B (2)	3,1
120412SN	1,2	0,18	25°	B (2)	3,1

P			
M			
K			
N			
S			
H		●	
O		●	●

## CNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners




**71 003 ...** **71 003 ...** **71 003 ...**

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
120404SN	0,4	0,14	20°	B (2)	3,3
120404SN	0,4	0,20	35°	B (2)	3,3
120408SN	0,8	0,14	20°	B (2)	3,3
120408SN	0,8	0,20	35°	B (2)	3,3
120412SN	1,2	0,14	20°	B (2)	3,1
120412SN	1,2	0,20	35°	B (2)	3,1



P			
M			
K			
N			
S			
H	●	●	●
O			

**DNGA**

Designation	L mm	S mm	D1 mm	IC mm
DNGA 1506..	15,5	6,35	5,16	12,7

**DNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners





ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
150604EN	0,4			B (2)	3,6
150604SN	0,4	0,14	20°	B (2)	3,6
150608EN	0,8			B (2)	3,3
150608SN	0,8	0,14	20°	B (2)	3,3
150612EN	1,2			B (2)	3,0
150612SN	1,2	0,14	20°	B (2)	3,0

70002	80002	90002
70302	80302	90302
70602	80602	90602

P			
M			
K			
N			
S			
H		●	
O		●	●

## DNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners





ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
150604SN	0,4	0,09	15°	B (2)	3,6
150604SN	0,4	0,18	25°	B (2)	3,6
150608SN	0,8	0,09	15°	B (2)	3,3
150608SN	0,8	0,18	25°	B (2)	3,3
150612SN	1,2	0,09	15°	B (2)	3,0
150612SN	1,2	0,18	25°	B (2)	3,0

71 017 ...	71 017 ...	71 017 ...
70102	80102	90102
70402	80402	90402
70702	80702	90702

P	M	K	N	S	H	O
					•	
					•	
					•	

## DNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners




ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
150604SN	0,4	0,14	20°	B (2)	3,6
150604SN	0,4	0,20	35°	B (2)	3,6
150608SN	0,8	0,14	20°	B (2)	3,3
150608SN	0,8	0,20	35°	B (2)	3,3
150612SN	1,2	0,14	20°	B (2)	3,0
150612SN	1,2	0,20	35°	B (2)	3,0

71 017 ...	71 017 ...	71 017 ...
70202	80202	90202
70502	80502	90502
70802	80802	90802

P	M	K	N	S	H	O
					•	
					•	
					•	

**SNGA**

Designation	L mm	S mm	D1 mm	IC mm
SNGA 1204..	12,7	4,76	5,16	12,7

**SNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners





NEW	NEW	NEW
CTBH1000C	CTBH2000C	CTBH3000C
F PCBN SNGA	F PCBN SNGA	F PCBN SNGA
71 039 ...	71 039 ...	71 039 ...
70002	80002	90002

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
120408EN	0,8			B (2)	3,8
120408SN	0,8	0,14	20°	B (2)	3,8
120412EN	1,2			B (2)	3,8
120412SN	1,2	0,14	20°	B (2)	3,8

P			
M			
K			
N			
S			
H			
O			

## SNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners





ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
120408SN	0,8	0,09	15°	B (2)	3,8
120408SN	0,8	0,18	25°	B (2)	3,8
120412SN	1,2	0,09	15°	B (2)	3,8
120412SN	1,2	0,18	25°	B (2)	3,8

71 039 ...	71 039 ...	71 039 ...
70102	80102	90102
70402	80402	90402

P			
M			
K			
N			
S			
H		•	•
O		•	•

## SNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners




ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
120408SN	0,8	0,14	20°	B (2)	3,8
120408SN	0,8	0,20	35°	B (2)	3,8
120412SN	1,2	0,14	20°	B (2)	3,8
120412SN	1,2	0,20	35°	B (2)	3,8

71 039 ...	71 039 ...	71 039 ...
70202	80202	90202
70502	80502	90502



P			
M			
K			
N			
S			
H	•	•	•
O			

**TNGA**

Designation	L mm	S mm	D1 mm	IC mm
TNGA 1604..	16,5	4,76	3,81	9,52

**TNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners





ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
160404EN	0,4			C (3)	3,6
160404SN	0,4	0,14	20°	C (3)	3,6
160408EN	0,8			C (3)	3,3
160408SN	0,8	0,14	20°	C (3)	3,3
160412EN	1,2			C (3)	3,0
160412SN	1,2	0,14	20°	C (3)	3,0

71 040 ...	70002	80002	90002
71 040 ...	70302	80302	90302
71 040 ...	70602	80602	90602

P				
M				
K				
N				
S				
H		•	•	•
O				


**TNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners





ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
160404SN	0,4	0,09	15°	C (3)	3,6
160404SN	0,4	0,18	25°	C (3)	3,6
160408SN	0,8	0,09	15°	C (3)	3,3
160408SN	0,8	0,18	25°	C (3)	3,3
160412SN	1,2	0,09	15°	C (3)	3,0
160412SN	1,2	0,18	25°	C (3)	3,0

71 040 ... 71 040 ... 71 040 ...


**TNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners




ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
160404SN	0,4	0,14	20°	C (3)	3,6
160404SN	0,4	0,20	35°	C (3)	3,6
160408SN	0,8	0,14	20°	C (3)	3,3
160408SN	0,8	0,20	35°	C (3)	3,3
160412SN	1,2	0,14	20°	C (3)	3,0
160412SN	1,2	0,20	35°	C (3)	3,0

71 040 ... 71 040 ... 71 040 ...





**VNGA**

Designation	L mm	S mm	D1 mm	IC mm
VNGA 1604..	16,6	4,76	3,81	9,52

**VNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners





71 042 ...	71 042 ...	71 042 ...
70002	80002	90002
70302	80302	90302

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
160404EN	0,4			B (2)	5,1
160404SN	0,4	0,14	20°	B (2)	5,1
160408EN	0,8			B (2)	4,2
160408SN	0,8	0,14	20°	B (2)	4,2

P			
M			
K			
N			
S			
H			•
O			•
			•

## VNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners





ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
160404SN	0,4	0,09	15°	B (2)	5,1
160404SN	0,4	0,18	25°	B (2)	5,1
160408SN	0,8	0,09	15°	B (2)	4,2
160408SN	0,8	0,18	25°	B (2)	4,2

71 042 ...	71 042 ...	71 042 ...
70102	80102	90102
70402	80402	90402

P			
M			
K			
N			
S			
H		•	•
O		•	•

## VNGA

▲ TCE(NOI) = Design and number of equipped cutting edge corners




ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
160404SN	0,4	0,14	20°	B (2)	5,1
160404SN	0,4	0,20	35°	B (2)	5,1
160408SN	0,8	0,14	20°	B (2)	4,2
160408SN	0,8	0,20	35°	B (2)	4,2

71 042 ...	71 042 ...	71 042 ...
70202	80202	90202
70502	80502	90502



P			
M			
K			
N			
S			
H	•	•	•
O			

**WNGA**

Designation	L mm	S mm	D1 mm	IC mm
WNGA 0804..	8,5	4,76	5,13	12,7

**WNGA**

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**71 044 ...**      **71 044 ...**      **71 044 ...**

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
080408EN	0,8			C (3)	3,3
080408SN	0,8	0,14	20°	C (3)	3,3
080412EN	1,2			C (3)	3,1
080412SN	1,2	0,14	20°	C (3)	3,1



70002      80002      90002

70302      80302      90302

P			
M			
K			
N			
S			
H		●	●
O			●

## WNGA


▲ TCE(NOI) = Design and number of equipped cutting edge corners



ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
080408SN	0,8	0,09	15°	C (3)	3,3
080408SN	0,8	0,18	25°	C (3)	3,3
080412SN	1,2	0,09	15°	C (3)	3,1
080412SN	1,2	0,18	25°	C (3)	3,1



71 044 ... 71 044 ... 71 044 ...

70102 80102 90102  
70402 80402 90402



## WNGA


▲ TCE(NOI) = Design and number of equipped cutting edge corners



ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
080408SN	0,8	0,14	20°	C (3)	3,3
080408SN	0,8	0,20	35°	C (3)	3,3
080412SN	1,2	0,14	20°	C (3)	3,1
080412SN	1,2	0,20	35°	C (3)	3,1


71 044 ... 71 044 ... 71 044 ...

70202 80202 90202  
70502 80502 90502




## CCGW

Designation	L mm	S mm	D1 mm	IC mm
CCGW 0602..	6,45	2,38	2,8	6,35
CCGW 09T3..	9,70	3,97	4,4	9,52



## CCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners





71 000 ... 71 000 ... 71 000 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm			
060202EN	0,2			B (2)	2,9			
060202SN	0,2	0,14	20°	B (2)	2,9	70002	80002	90002
060204EN	0,4			B (2)	2,9	70302	80302	90302
060204SN	0,4	0,14	20°	B (2)	2,9			
09T302EN	0,2			B (2)	3,3	70602	80602	90602
09T302SN	0,2	0,14	20°	B (2)	3,3			
09T304EN	0,4			B (2)	3,3	70902	80902	90902
09T304SN	0,4	0,14	20°	B (2)	3,3			
09T308EN	0,8			B (2)	3,3	71202	81202	91202
09T308SN	0,8	0,14	20°	B (2)	3,3			
P								
M								
K								
N								
S						●		
H						●		
O						●		

## CCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**M**  
PCBN  
CCGW

71 000 ...

**M**  
PCBN  
CCGW

71 000 ...

**M**  
PCBN  
CCGW



71 000 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
060202SN	0,2	0,09	15°	B (2)	2,9
060202SN	0,2	0,18	25°	B (2)	2,9
060204SN	0,4	0,09	15°	B (2)	2,9
060204SN	0,4	0,18	25°	B (2)	2,9
09T302SN	0,2	0,09	15°	B (2)	3,3
09T302SN	0,2	0,18	25°	B (2)	3,3
09T304SN	0,4	0,09	15°	B (2)	3,3
09T304SN	0,4	0,18	25°	B (2)	3,3
09T308SN	0,8	0,09	15°	B (2)	3,3
09T308SN	0,8	0,18	25°	B (2)	3,3

P				
M				
K				
N				
S				
H			•	
O			•	•

## CCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**R**  
PCBN  
CCGW


71 000 ... 71 000 ... 71 000 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
060202SN	0,2	0,14	20°	B (2)	2,9
060202SN	0,2	0,20	35°	B (2)	2,9
060204SN	0,4	0,14	20°	B (2)	2,9
060204SN	0,4	0,20	35°	B (2)	2,9
09T302SN	0,2	0,14	20°	B (2)	3,3
09T302SN	0,2	0,20	35°	B (2)	3,3
09T304SN	0,4	0,14	20°	B (2)	3,3
09T304SN	0,4	0,20	35°	B (2)	3,3
09T308SN	0,8	0,14	20°	B (2)	3,3
09T308SN	0,8	0,20	35°	B (2)	3,3

P			
M			
K			
N			
S			
H		•	•
O			•


## DCGW

Designation	L mm	S mm	D1 mm	IC mm
DCGW 0702..	7,75	2,38	2,38	6,35
DCGW 11T3..	11,60	3,97	4,40	9,52



## DCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



F  
PCBN  
DCGW

71 007 ...

71 007 ...



71 007 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm			
070202EN	0,2			B (2)	3,7		70002	
070202SN	0,2	0,14	20°	B (2)	3,7			80002
070204EN	0,4			B (2)	3,6		70302	
070204SN	0,4	0,14	20°	B (2)	3,6			90302
070208EN	0,8			B (2)	3,3		71202	
070208SN	0,8	0,14	20°	B (2)	3,3			91202
11T302EN	0,2			B (2)	3,7		70602	
11T302SN	0,2	0,14	20°	B (2)	3,7			90602
11T304EN	0,4			B (2)	3,6		70902	
11T304SN	0,4	0,14	20°	B (2)	3,6			90902
11T308EN	0,8			B (2)	3,3		71302	
11T308SN	0,8	0,14	20°	B (2)	3,3			91302

P								
M								
K								
N								
S								
H						●	●	●
O								

## DCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**M**  
PCBN  
DCGW



**71 007 ...**

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
070202SN	0,2	0,09	15°	B (2)	3,7
070202SN	0,2	0,18	25°	B (2)	3,7
070204SN	0,4	0,09	15°	B (2)	3,6
070204SN	0,4	0,18	25°	B (2)	3,6
070208SN	0,8	0,09	15°	B (2)	3,3
070208SN	0,8	0,18	25°	B (2)	3,3
11T302SN	0,2	0,09	15°	B (2)	3,7
11T302SN	0,2	0,18	25°	B (2)	3,7
11T304SN	0,4	0,09	15°	B (2)	3,6
11T304SN	0,4	0,18	25°	B (2)	3,6
11T308SN	0,8	0,09	15°	B (2)	3,3
11T308SN	0,8	0,18	25°	B (2)	3,3

P			
M			
K			
N			
S			
H	•	•	•
O			

## DCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**R**  
PCBN  
DCGW


71 007 ... 71 007 ... 71 007 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm			
070202SN	0,2	0,14	20°	B (2)	3,7		70202	
070202SN	0,2	0,20	35°	B (2)	3,7		80202	90202
070204SN	0,4	0,14	20°	B (2)	3,6		70502	
070204SN	0,4	0,20	35°	B (2)	3,6		80502	90502
070208SN	0,8	0,14	20°	B (2)	3,3		71602	
070208SN	0,8	0,20	35°	B (2)	3,3		81602	91602
11T302SN	0,2	0,14	20°	B (2)	3,7		70802	
11T302SN	0,2	0,20	35°	B (2)	3,7		80802	90802
11T304SN	0,4	0,14	20°	B (2)	3,6		71102	
11T304SN	0,4	0,20	35°	B (2)	3,6		81102	91102
11T308SN	0,8	0,14	20°	B (2)	3,3		71702	
11T308SN	0,8	0,20	35°	B (2)	3,3		81702	91702



P			
M			
K			
N			
S			
H	•	•	•
O			

**TCGW**

Designation	L mm	S mm	D1 mm	IC mm
TCGW 1102..	11,0	2,38	2,8	6,35
TCGW 16T3..	16,5	3,97	4,4	9,52

**TCGW**

▲ TCE(NOI) = Design and number of equipped cutting edge corners





71 034 ... 71 034 ... 71 034 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm			
110204EN	0,4			C (3)	3,6			
110204SN	0,4	0,14	20°	C (3)	3,6	70002	80002	90002
110208EN	0,8			C (3)	3,3	70302	80302	90302
110208SN	0,8	0,14	20°	C (3)	3,3			
16T304EN	0,4			C (3)	3,6	70602	80602	90602
16T304SN	0,4	0,14	20°	C (3)	3,6			
16T308EN	0,8			C (3)	3,3	70902	80902	90902
16T308SN	0,8	0,14	20°	C (3)	3,3			

P				
M				
K				
N				
S				
H			•	•
O			•	•

## TCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**M**  
PCBN  
TCGW



71 034 ... 71 034 ... 71 034 ...

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
110204SN	0,4	0,09	15°	C (3)	3,6
110204SN	0,4	0,18	25°	C (3)	3,6
110208SN	0,8	0,09	15°	C (3)	3,3
110208SN	0,8	0,18	25°	C (3)	3,3
16T304SN	0,4	0,09	15°	C (3)	3,6
16T304SN	0,4	0,18	25°	C (3)	3,6
16T308SN	0,8	0,09	15°	C (3)	3,3
16T308SN	0,8	0,18	25°	C (3)	3,3

P				
M				
K				
N				
S				
H			•	
O			•	•

## TCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**R**  
PCBN  
TCGW

71 034 ...

71 034 ...

71 034 ...


ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
110204SN	0,4	0,14	20°	C (3)	3,6
110204SN	0,4	0,20	35°	C (3)	3,6
110208SN	0,8	0,14	20°	C (3)	3,3
110208SN	0,8	0,20	35°	C (3)	3,3
16T304SN	0,4	0,14	20°	C (3)	3,6
16T304SN	0,4	0,20	35°	C (3)	3,6
16T308SN	0,8	0,14	20°	C (3)	3,3
16T308SN	0,8	0,20	35°	C (3)	3,3

70202      80202      90202  
 70502      80502      90502  
 70802      80802      90802  
 71102      81102      91102

P			
M			
K			
N			
S			
H		•	•
O		•	•



## VCGW

Designation	L mm	S mm	D1 mm	IC mm
VCGW 1103..	11,1	3,18	2,9	6,35
VCGW 1604..	16,6	4,76	4,4	9,52



## VCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners





ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm	71 041 ...	71 041 ...	71 041 ...
110302EN	0,2			B (2)	5,5	70002	80002	
110302SN	0,2	0,14	20°	B (2)	5,5			90002
110304EN	0,4			B (2)	5,1	70302	80302	
110304SN	0,4	0,14	20°	B (2)	5,1			90302
160402EN	0,2			B (2)	5,5	70602	80602	
160402SN	0,2	0,14	20°	B (2)	5,5			90602
160404EN	0,4			B (2)	5,1	70902	80902	
160404SN	0,4	0,14	20°	B (2)	5,1			90902
160408EN	0,8			B (2)	4,2	71202	81202	
160408SN	0,8	0,14	20°	B (2)	4,2			91202

P				
M				
K				
N				
S				
H			•	•
O			•	•

## VCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**M**  
PCBN  
VCGW



**71 041 ...**

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
110302SN	0,2	0,09	15°	B (2)	5,5
110302SN	0,2	0,18	25°	B (2)	5,5
110304SN	0,4	0,09	15°	B (2)	5,1
110304SN	0,4	0,18	25°	B (2)	5,1
160402SN	0,2	0,09	15°	B (2)	5,5
160402SN	0,2	0,18	25°	B (2)	5,5
160404SN	0,4	0,09	15°	B (2)	5,1
160404SN	0,4	0,18	25°	B (2)	5,1
160408SN	0,8	0,09	15°	B (2)	4,2
160408SN	0,8	0,18	25°	B (2)	4,2

P			
M			
K			
N			
S			
H		•	
O		•	•

## VCGW

▲ TCE(NOI) = Design and number of equipped cutting edge corners



**R**  
PCBN  
VCGW

**71 041 ...**

**71 041 ...**

**71 041 ...**

ISO	RE mm	BN mm	GB	TCE (NOI)	LE mm
110302SN	0,2	0,14	20°	B (2)	5,5
110302SN	0,2	0,20	35°	B (2)	5,5
110304SN	0,4	0,14	20°	B (2)	5,1
110304SN	0,4	0,20	35°	B (2)	5,1
160402SN	0,2	0,14	20°	B (2)	5,5
160402SN	0,2	0,20	35°	B (2)	5,5
160404SN	0,4	0,14	20°	B (2)	5,1
160404SN	0,4	0,20	35°	B (2)	5,1
160408SN	0,8	0,14	20°	B (2)	4,2
160408SN	0,8	0,20	35°	B (2)	4,2

P				
M				
K				
N				
S				
H			•	
O			•	•

# Cutting data standard values for negative PCBN inserts

Index	Cutting edges code negative insert*			Ra (theo.)	Cutting condition	Main Application	CTBH 1000C				
	Material	Strength	X				EN-F				
H.1.1				46–55 HRC	Smooth	•	v <sub>c</sub>	f	a <sub>p</sub>		
X			Smooth	•	200	0,06–0,15	0,05–0,5				
X			Interrupted	○							
X			Extremely interrupted								
Hardened steel		X	Smooth	•	220	0,06–0,15	0,05–0,5				
		X	Interrupted	○							
		X	Extremely interrupted								
H.1.3		X	Smooth	•	220	0,06–0,15	0,05–0,5				
		X	Interrupted	○							
		X	Extremely interrupted								
H.1.4		X	Smooth	•	240	0,06–0,15	0,05–0,5				
		X	Interrupted	○							
		X	Extremely interrupted								
H.2.1	Chilled iron	400 HB	X	Smooth							
H.3.1	Hardened cast iron	55 HRC	X	Interrupted							
			X	Extremely interrupted							

Index	Cutting edges code negative insert*			Ra (theo.)	Cutting condition	Main Application	CTBH 2000C				
	Material	Strength	X				EN-F				
H.1.1				46–55 HRC	Smooth	•	160	0,06–0,15	0,1–0,5		
X			Smooth	•	160	0,06–0,15	0,1–0,5				
X			Interrupted	•							
X			Extremely interrupted	○							
Hardened steel		X	Smooth	•	180	0,06–0,15	0,1–0,5				
		X	Interrupted	•	180	0,06–0,15	0,1–0,5				
		X	Extremely interrupted	○							
H.1.3		X	Smooth	•	180	0,06–0,15	0,1–0,5				
		X	Interrupted	•	180	0,06–0,15	0,1–0,5				
		X	Extremely interrupted	○							
H.1.4		X	Smooth	•	200	0,06–0,15	0,1–0,5				
		X	Interrupted	•	200	0,06–0,15	0,1–0,5				
		X	Extremely interrupted	○							
H.2.1	Chilled iron	400 HB	X	Smooth							
H.3.1	Hardened cast iron	55 HRC	X	Interrupted							
			X	Extremely interrupted							

Index	Cutting edges code negative insert*			Ra (theo.)	Cutting condition	Main Application	CTBH 3000C				
	Material	Strength	X				SN-014D-F				
H.1.1				46–55 HRC	Smooth	○	180	0,06–0,15	0,1–0,5		
X			Smooth	•	180	0,06–0,15	0,1–0,5				
X			Interrupted	•	180	0,06–0,15	0,1–0,5				
X			Extremely interrupted	•	180	0,06–0,15	0,1–0,5				
Hardened steel		X	Smooth	○	200	0,06–0,15	0,1–0,5				
		X	Interrupted	•	200	0,06–0,15	0,1–0,5				
		X	Extremely interrupted	•	200	0,06–0,15	0,1–0,5				
H.1.3		X	Smooth	○	200	0,06–0,15	0,1–0,5				
		X	Interrupted	•	200	0,06–0,15	0,1–0,5				
		X	Extremely interrupted	•	200	0,06–0,15	0,1–0,5				
H.1.4		X	Smooth	○	220	0,06–0,15	0,1–0,5				
		X	Interrupted	•	220	0,06–0,15	0,1–0,5				
		X	Extremely interrupted	•	220	0,06–0,15	0,1–0,5				
H.2.1	Chilled iron	400 HB	X	Smooth	○	200	0,08–0,15	0,1–0,4			
H.3.1	Hardened cast iron	55 HRC	X	Interrupted	○	180	0,05–0,12	0,1–0,4			
			X	Extremely interrupted	○	160	0,05–0,12	0,1–0,4			
			X	Smooth	○	200	0,08–0,15	0,1–0,4			
			X	Interrupted	○	180	0,05–0,12	0,1–0,4			
			X	Extremely interrupted	○	160	0,05–0,12	0,1–0,4			

 With our PCBN indexable inserts, we recommend dry machining – information about this can be found on page 50


 \* Note chamfer width: The wider the chamfer, the more stable the cutting edge.

 The cutting data is strongly influenced by external conditions, such as the stability of the tool and workpiece clamping, material and type of machine. The specified values represent guideline cutting data that can be adjusted by approx. ±20% according to the usage conditions.

CTBH 1000C					
SN-009C-M			SN-014D-R		
1,0–3,2			0,5–1,6		
v <sub>c</sub>	f	a <sub>p</sub>	v <sub>c</sub>	f	a <sub>p</sub>
200	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
200	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
220	0,06–0,15	0,1–0,5	200	0,06–0,25	0,12–0,5
220	0,06–0,15	0,1–0,5	200	0,06–0,25	0,12–0,5
220	0,06–0,15	0,1–0,5	200	0,06–0,25	0,12–0,5
220	0,06–0,15	0,1–0,5	200	0,06–0,25	0,12–0,5
240	0,06–0,15	0,1–0,5	220	0,06–0,25	0,12–0,5
240	0,06–0,15	0,1–0,5	220	0,06–0,25	0,12–0,5

CTBH 2000C					
SN-009C-M			SN-014D-R		
1,0–4,5			0,8–3,0		
v <sub>c</sub>	f	a <sub>p</sub>	v <sub>c</sub>	f	a <sub>p</sub>
160	0,06–0,15	0,1–0,5	140	0,06–0,25	0,12–0,5
160	0,06–0,15	0,1–0,5	140	0,06–0,25	0,12–0,5
160	0,06–0,15	0,1–0,5	140	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
200	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
200	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
200	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5

CTBH 3000C					
SN-018E-M			SN-020G-R		
1,6–3,2			0,8–3,0		
v <sub>c</sub>	f	a <sub>p</sub>	v <sub>c</sub>	f	a <sub>p</sub>
150	0,06–0,25	0,1–0,5	150	0,08–0,4	0,15–0,5
150	0,06–0,25	0,1–0,5	150	0,08–0,4	0,15–0,5
150	0,06–0,25	0,1–0,5	150	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
190	0,06–0,25	0,1–0,5	190	0,08–0,4	0,15–0,5
190	0,06–0,25	0,1–0,5	190	0,08–0,4	0,15–0,5
190	0,06–0,25	0,1–0,5	190	0,08–0,4	0,15–0,5
190	0,06–0,25	0,1–0,5	190	0,08–0,4	0,15–0,5
180	0,08–0,2	0,1–0,5	180	0,08–0,2	0,15–0,5
160	0,08–0,15	0,1–0,5	160	0,08–0,15	0,15–0,5
140	0,08–0,15	0,1–0,5	140	0,08–0,15	0,15–0,5
180	0,08–0,2	0,1–0,5	180	0,08–0,2	0,15–0,5
160	0,08–0,15	0,1–0,5	160	0,08–0,15	0,15–0,5
140	0,08–0,15	0,1–0,5	140	0,08–0,15	0,15–0,5



## Cutting data standard values for positive PCBN inserts

Index	Cutting edges code positive insert*			Ra (theo.)	Cutting condition	Main Application	CTBH 1000C					
	Material	Strength					EN-F		1,6–6,4			
H.1.1					Smooth	●	v <sub>c</sub>	f				
					Interrupted	○	230	0,06–0,15				
					Extremely interrupted							
							250	0,06–0,15				
					Smooth	●	250	0,06–0,15				
					Interrupted	○	270	0,06–0,15				
					Extremely interrupted							
					Smooth							
					Interrupted							
					Extremely interrupted							
H.2.1	Chilled iron	400 HB			Smooth							
					Interrupted							
					Extremely interrupted							
H.3.1	Hardened cast iron	55 HRC			Smooth							
					Interrupted							
					Extremely interrupted							

Index	Cutting edges code positive insert*			Ra (theo.)	Cutting condition	Main Application	CTBH 2000C					
	Material	Strength					EN-F		1,6–6,4			
H.1.1					Smooth	●	180	0,06–0,15				
					Interrupted	●	180	0,06–0,15				
					Extremely interrupted	○						
							210	0,06–0,15				
					Smooth	●	210	0,06–0,15				
					Interrupted	●	210	0,06–0,15				
					Extremely interrupted	○						
							230	0,06–0,15				
					Smooth	●	230	0,06–0,15				
					Interrupted	●	230	0,06–0,15				
					Extremely interrupted	○						
H.2.1	Chilled iron	400 HB			Smooth							
					Interrupted							
					Extremely interrupted							
H.3.1	Hardened cast iron	55 HRC			Smooth							
					Interrupted							
					Extremely interrupted							

Index	Cutting edges code positive insert*			Ra (theo.)	Cutting condition	Main Application	CTBH 3000C					
	Material	Strength					SN-014D-F		1,0–3,2			
H.1.1					Smooth	○	210	0,06–0,15				
					Interrupted	●	180	0,06–0,15				
					Extremely interrupted	●	180	0,06–0,15				
							230	0,06–0,15				
					Smooth	●	200	0,06–0,15				
					Interrupted	●	200	0,06–0,15				
					Extremely interrupted	●	200	0,06–0,15				
							250	0,06–0,15				
					Smooth	○	220	0,06–0,15				
					Interrupted	●	220	0,06–0,15				
					Extremely interrupted	●	220	0,06–0,15				
H.2.1	Chilled iron	400 HB			Smooth	○	230	0,08–0,15				
					Interrupted	○	210	0,05–0,12				
					Extremely interrupted	○	180	0,05–0,12				
							230	0,08–0,15				
H.3.1	Hardened cast iron	55 HRC			Smooth	○	210	0,05–0,12				
					Interrupted	○	180	0,05–0,12				
					Extremely interrupted	○	180	0,05–0,12				

With our PCBN indexable inserts, we recommend dry machining – information about this can be found on page 50


\* Note chamfer width: The wider the chamfer, the more stable the cutting edge.

The cutting data is strongly influenced by external conditions, such as the stability of the tool and workpiece clamping, material and type of machine. The specified values represent guideline cutting data that can be adjusted by approx.  $\pm 20\%$  according to the usage conditions.

CTBH 1000C					
SN-009C-M			SN-014D-R		
1,0–3,2			0,5–1,6		
v <sub>c</sub>	f	a <sub>p</sub>	v <sub>c</sub>	f	a <sub>p</sub>
230	0,06–0,15	0,1–0,5	210	0,06–0,25	0,12–0,5
230	0,06–0,15	0,1–0,5	210	0,06–0,25	0,12–0,5
250	0,06–0,15	0,1–0,5	230	0,06–0,25	0,12–0,5
250	0,06–0,15	0,1–0,5	230	0,06–0,25	0,12–0,5
250	0,06–0,15	0,1–0,5	230	0,06–0,25	0,12–0,5
250	0,06–0,15	0,1–0,5	230	0,06–0,25	0,12–0,5
270	0,06–0,15	0,1–0,5	250	0,06–0,25	0,12–0,5
270	0,06–0,15	0,1–0,5	250	0,06–0,25	0,12–0,5


CTBH 2000C					
SN-009C-M			SN-014D-R		
1,0–4,5			0,8–3,0		
v <sub>c</sub>	f	a <sub>p</sub>	v <sub>c</sub>	f	a <sub>p</sub>
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	160	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
180	0,06–0,15	0,1–0,5	180	0,06–0,25	0,12–0,5
200	0,06–0,15	0,1–0,5	210	0,06–0,25	0,12–0,5
200	0,06–0,15	0,1–0,5	210	0,06–0,25	0,12–0,5
200	0,06–0,15	0,1–0,5	210	0,06–0,25	0,12–0,5

CTBH 3000C					
SN-018E-M			SN-020G-R		
1,6–3,2			0,8–3,0		
v <sub>c</sub>	f	a <sub>p</sub>	v <sub>c</sub>	f	a <sub>p</sub>
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
170	0,06–0,25	0,1–0,5	170	0,08–0,4	0,15–0,5
195	0,06–0,25	0,1–0,5	195	0,08–0,4	0,15–0,5
195	0,06–0,25	0,1–0,5	195	0,08–0,4	0,15–0,5
195	0,06–0,25	0,1–0,5	195	0,08–0,4	0,15–0,5
195	0,06–0,25	0,1–0,5	195	0,08–0,4	0,15–0,5
195	0,06–0,25	0,1–0,5	195	0,08–0,4	0,15–0,5
195	0,06–0,25	0,1–0,5	195	0,08–0,4	0,15–0,5
195	0,06–0,25	0,1–0,5	195	0,08–0,4	0,15–0,5
220	0,06–0,25	0,1–0,5	220	0,08–0,4	0,15–0,5
220	0,06–0,25	0,1–0,5	220	0,08–0,4	0,15–0,5
220	0,06–0,25	0,1–0,5	220	0,08–0,4	0,15–0,5
210	0,08–0,2	0,1–0,5	210	0,08–0,2	0,15–0,5
180	0,08–0,15	0,1–0,5	180	0,08–0,15	0,15–0,5
160	0,08–0,15	0,1–0,5	160	0,08–0,15	0,15–0,5
210	0,08–0,2	0,1–0,5	210	0,08–0,2	0,15–0,5
180	0,08–0,15	0,1–0,5	180	0,08–0,15	0,15–0,5
160	0,08–0,15	0,1–0,5	160	0,08–0,15	0,15–0,5



## Wet or dry machining

The heat produced during hard turning is distributed as 80% to the chip, 10% to the component and 10% to the indexable insert. This underlines the importance of the correct chip removal from the cutting zone. There is therefore generally no need to use cooling lubricant. Machining without cooling lubricant supply is the ideal situation. PCBN indexable inserts withstand high temperatures, thus reducing the costs and problems associated with cooling lubricant. For some applications, cooling lubricant is however necessary to keep the temperature of the component constant. During the whole turning application, a continuous supply of cooling lubricant should be ensured. A temperature shock on the cutting edge must be avoided.



## Advantages of hard turning over grinding

In the past, grinding was a common method used to finish components made of hardened steel. Today, hard turning is considered an efficient and cost-effective alternative. Hard turning can increase productivity massively and offers significant environmental benefits.

- ▲ High surface quality is possible (up to  $R_a$  0.2 µm)
- ▲ Lower machine investment costs
- ▲ Shorter production time per workpiece
- ▲ Process flexibility (internal and external machining on one machine is possible)
- ▲ Complex geometries are easier to produce
- ▲ Shorter setup times
- ▲ Low tool costs (no formed grinding wheels)
- ▲ No cooling lubricant required
- ▲ Chips are more cost-efficient and easier to recycle
- ▲ No grinding sludge

## Cutting data effect on wear

### Cutting data and wear

Sufficient heat in the cutting zone leads to reduced cutting forces. If the cutting speed is too low, it generates too little energy and therefore less heat, which can subsequently cause a cutting edge breakage.

Crater wear affects the stability of the indexable insert, but only has a secondary effect on the surface quality of the workpiece. In contrast, flank wear affects the tolerance and geometrical accuracy.



#### Crater wear

Crater wear is the most dominant type of wear when machining case-hardened steel.

It is caused by the chemical wear resulting from extremely high temperatures and forces, which are generated at the cutting edge contact point.

Crater wear weakens the cutting edge.




#### Flank wear

With abrasive steels such as bearing steel or tool steel, there is mainly flank wear.

This has a negative effect on the surface and dimensional accuracy.

Tool life related wear




The matter of wear is extremely complex, but there are nevertheless ways to control it and ensure a stable and reliable production process. More information on this can be found on the next pages.

## Benefits of the coating

The PVD layer system improves the oxidation resistance and protects against adhesion. The compressive stresses introduced by the coating process stabilise the system cutting material – cutting edge – coating. This leads to a better connection to the base material and a significantly greater process security.

By increasing the tool life and increasing the feeds, the machining times and the costs per workpiece are reduced significantly. The use of existing resources is hereby reduced and the competitiveness is increased considerably.


- ▲ The PVD coating protects the PCBN against the chemical interaction with oxygen during machining. Oxidation and diffusion wear are significantly reduced.
- ▲ At machining temperature, harder and more resistant to reactions than binder phase (TiN, TiCN)
- ▲ Offers additional wear protection especially for PCBN grades with a low CBN content.



## Criteria for an indexable insert change

A key criterion for the indexable insert change during hard turning is the surface quality. The definition of the surface quality of the design on the drawing provides a measurable parameter. When the specified value is reached, this leads to an indexable insert change.


The specified number of workpieces should be below 10-20% of the average tool life of an optimised production process. The exact number of workpieces must be defined for every process.



## Calculating the surface quality

The theoretical surface profile ( $R_z / R_t / R_a$ ) can be calculated based on the radius and feed. The desired surface quality can hereby be calculated in advance as long as all relevant environmental conditions are OK. For example, poorer values are obtained with unstable machines, unstable workpieces, poor clamping, defective and incorrect tool systems.

When hard turning with PCBN, the calculated theoretical profile height is essentially undercut. A special machining mechanism (self-induced hot machining) with a high cutting pressure is created. Through this, the theoretical profile is smoothed and the surface quality is improved.



$$R_{th} = \frac{f^2}{8 \cdot r_\varepsilon} \quad r_\varepsilon = \frac{f^2}{8 \cdot R_{th}}$$

$$f = \sqrt{8 \cdot r_\varepsilon \cdot R_{th}} \quad R_{th} \approx R_z \\ r_\varepsilon = RE$$

### Feed rate guide values for surface finish quality

Roughness range $R_z$ in $\mu\text{m}$	$R_{th}$	Corresponds to $R_a$	Roughness index	ISO 1302	Corner radius RE in mm and feed f in mm/rev						
					RE = 0,1	RE = 0,2	RE = 0,4	RE = 0,8	RE = 1,2	RE = 1,6	RE = 2,4
63–100	$\sqrt{R_{th} \cdot 63}$	12,5–25	N11	25/	0,22*	0,32*	0,45*	0,63	0,78	0,9	1,1
40–63	$\sqrt{R_{th} \cdot 40}$	6,3–12,5	N10	12,5/	0,18*	0,25*	0,36	0,51	0,62	0,72	0,88
31,5–40	$\sqrt{R_{th} \cdot 31,5}$	4,9–6,3	N9	6,3/	0,16*	0,22*	0,32	0,45	0,55	0,63	0,78
25–31,5	$\sqrt{R_{th} \cdot 25}$	4,0–4,9			0,14*	0,2*	0,28	0,4	0,49	0,57	0,69
16–25	$\sqrt{R_{th} \cdot 16}$	2,5–4,0	N8	3,2/	0,11*	0,16	0,23	0,32	0,39	0,45	0,55
10–16	$\sqrt{R_{th} \cdot 10}$	1,6–2,5			0,09	0,13	0,18	0,25	0,31	0,36	0,44
6,3–10	$\sqrt{R_{th} \cdot 6,3}$	1,0–1,6	N7	1,6/	0,07	0,1	0,14	0,2	0,25	0,28	0,35
4–6,3	$\sqrt{R_{th} \cdot 4}$	0,8–1,0	N6	0,8/	0,06	0,08	0,11	0,16	0,2	0,23	0,28
2,5–4	$\sqrt{R_{th} \cdot 2,5}$	0,4–0,8	N5	0,4/	0,04	0,06	0,09	0,13	0,15	0,18	0,22
1,6–2,5	$\sqrt{R_{th} \cdot 1,6}$	0,2–0,4	N4	0,2/	0,04	0,05	0,07	0,1	0,12	0,14	0,18
1–1,6	$\sqrt{R_{th} \cdot 1}$	0,1–0,2	N3	0,1/	0,03	0,04	0,06	0,08	0,1	0,11	0,14

\*Please ensure that the feed rate values used do not exceed the corner radius (RE).

The feed rate values shown are recommended values and are based on purely theoretical calculations using the above-mentioned formula. These may however deviate in practice.

## Single-cut or dual-cut machining

Whether single-cut or dual-cut machining should be selected, depends on the following factors:

- ▲ Machine capacity
- ▲ Dimensional accuracy
- ▲ Geometrical accuracy
- ▲ Surface quality

Often it is a case of balancing between accuracy and productivity.

**Single-cut machining**



### Single-cut machining

By using a high-quality machine tool and stable clamping, a single cut machining process can produce acceptable surface qualities and stable dimensions in many applications.

**Dual-cut machining**



### Dual-cut machining

In the case of unstable clamping, component batch fluctuations or where strict demands are placed on surface and dimension tolerances, dual-cut machining is advisable.

In this case it is advisable to work with two different widths of cut  $a_p$ .



## ISO designation system for inserts

Indexable inserts, CBN,  
ceramic – metric

C N G A 12 04 08 S N - 020D - B 3 - F

1	2	3	4	5	6	7	8	9	10	11	12	13
---	---	---	---	---	---	---	---	---	----	----	----	----

Indexable inserts, CBN,  
ceramic – inch

C N G A 4 3 2 S N - 020D - B 3 - F

1	2	3	4	5	6	7	8	9	10	11	12	13
---	---	---	---	---	---	---	---	---	----	----	----	----

1	Insert shape
V 35°	Included angle
D 55°	
E 75°	
C 80°	
M 86°	
K 55°	Included angle
B 82°	
A 85°	
L 90°	
P 108°	
H 120°	
O 135°	
R -	
S 90°	
T 60°	
W 80°	
Other shapes	

2	Clearance angle
$\alpha$	$\alpha$
A 3°	F 25°
B 5°	G 30°
C 7°	N 0°
D 15°	P 11°
E 20°	
O Clearance angles not included within the standard for which particular information is necessary.	


3	Tolerances					
IC $\pm$	BS					
mm	inch	mm	inch	mm	inch	
A	0,025	.0010	0,005	.0002	0,025	.001
F	0,013	.0005	0,005	.0002	0,025	.001
C	0,025	.0010	0,013	.0005	0,025	.001
H	0,013	.0005	0,013	.0005	0,025	.001
E	0,025	.0010	0,025	.0010	0,025	.001
G	0,025	.0010	0,025	.0010	0,13	.005
J	0,05-0,15*	.002-.006*	0,005	.0002	0,025	.001
K	0,05-0,15*	.002-.006*	0,013	.0005	0,025	.001
L	0,05-0,15*	.002-.006*	0,025	.0010	0,025	.001
M	0,05-0,15*	.002-.006*	0,05-0,20*	.003-.008*	0,13	.005
N	0,05-0,15*	.002-.006*	0,05-0,20*	.003-.008*	0,025	.001
U	0,08-0,25*	.003-.010*	0,13-0,38*	.005-.015*	0,13	.005


\* Depends on insert size

6	Insert thickness		
Code			
mm	inch	mm	inch
1,59	1/16	01	1
2,38	3/32	02	1.5
3,18	1/8	03	2
3,97	5/32	T3	2.5
4,76	3/16	04	3
5,56	7/32	05	3.5
6,35	1/4	06	4
7,94	5/16	07	5
9,52	3/8	09	6

7	Corner radius		
Code			
mm	inch	mm	inch
	00	X0	
≤ 0,05	.0015	00	X0
0,1	.004	01	0
0,2	.008	02	.5
0,4	$1/64$	04	1
0,8	$1/32$	08	2
1,2	$3/64$	12	3
1,6	$1/16$	16	4
2,0	$5/64$	20	5
2,4	$3/32$	24	6
2,8	$7/64$	28	7
3,2	$1/8$	32	8

8	Cutting edge
	Sharp
	rounded
	chamfered
	Chamfered and honed
	Double-chamfered
	Double-chamfered and honed
	Round chamfer





**4 Characteristics**

N		
R		
F		
A		
M, P		
G, P		
W		
T		
Q		
U		
B		
H		
C		
J		
X	Special version	

**inch**  
Change at inscribed circle  
IK < 1/4"

IK > 1/4"	IK < 1/4"
N / R / F	E
A / M / G	D
X	X

**5 Cutting length**

Type	ISO	ANSI	L		IC		
			mm	inch	mm	inch	
	06	2	6,4	.250	6,35	.250	
	09	3	9,7	.382	9,525	.375	
	12	4	12,9	.508	12,70	.500	
	16	5	16,1	.634	15,875	.625	
	19	6	19,3	.760	19,05	.750	
	25	8	25,8	1.016	25,4	1.000	
	32	12	35,24	1.269	31,75	1.250	
	06	2	6,35	.250	6,35	.250	
	09	3	9,525	.375	9,525	.375	
	12	4	12,7	.500	12,7	.500	
	15	5	15,875	.625	15,875	.625	
	19	6	19,05	.750	19,05	.750	
	25	8	25,4	1.000	25,4	1.000	
	31	10	31,75	1.250	31,75	1.250	
	07	2	7,7	.303	6,35	.250	
	11	3	11,6	.457	9,525	.375	
	15	4	15,5	.610	12,70	.500	
		11	2	11,1	.437	6,35	.250
		16	3	16,6	.653	9,525	.375
		22	4	22,10	.870	12,70	.500
			06	2	6,35	.250	6,35
08			-	8,0	.315	8,0	.315
09			3	9,52	.375	9,52	.375
10			-	10,0	.394	10,0	.394
12*	-		12,0	.472	12,0	.472	
12	4		12,7	.488	12,70	.488	
15	5		15,875	.625	15,875	.625	
	16	-	16,0	.630	16,0	.630	
	19	6	19,05	.750	19,05	.750	
	25	8	25,0	.984	25,0	.984	
	25*	-	25,4	1.000	25,4	1.000	
	31	10	31,75	1.250	31,75	1.250	
	32	-	32,0	1.260	32,0	1.260	

\* inch version

**10 Chamfer type**


	BN		T / S
	K / P <sup>1)</sup>		
	mm	inch	
015	0,15	.006	A 05°
020	0,20	.008	B 10°
025	0,25	.010	C 15°
050	0,50	.020	D 20°
075	0,75	.030	E 25°
100	1,00	.040	F 30°
			G 35°

1) Two letters are assigned for double-chamfered cutting edges e.g. BE =  
chamfer angle 1 ( $y_1$ ) = 10°  
chamfer angle 2 ( $y_2$ ) = 25°

**11 Number of cutting edges TCE(NOI)**

Single sided		Complete insert thickness	
A		T	
B		U	
C		V	
D		W	
G		X	
H		Y	
Double sided			
K		S	
L		F	
M		E	
N			
P			
Q			

Entire clamping flat



**13 Chip breaker designation**

F = Smooth cut  
M = Interrupted cut  
R = Strongly interrupted cut

A detailed chip breaker overview can be found in the main catalogue – Chapter 9 on → Pages 201–207

## ISO designation system for tool holders

P C L N R 20 20 K 12 - T

1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	----


UT50 - P C L N R -12

0	1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	---	----

HSK-T63 - D C L N R -12

0	1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	---	----



**0**  
**System/size**  
**UT** = UTS  
according to ISO 26622  
UT40 = UTS 40 mm  
UT50 = UTS 50 mm  
UT63 = UTS 63 mm  
  
**HSK-T**  
according to ISO 12164  
HSK-T63 = 63 mm  
HSK-T100 = 100 mm



**2**  
**Insert shape**


V 35°	Included angle
D 55°	
E 75°	
C 80°	
M 86°	
K 55°	Included angle
B 82°	
A 85°	
L 90°	
P 108°	
H 120°	
O 135°	
R -	
S 90°	
T 60°	
W 80°	

Other shapes





**8**  
**Tool length**

OAL		OAL		
mm	inch	mm	inch	
32	4.000	A	160	4.500
40	4.500	B	170	5.500
50	5.000	C	180	-
60	6.000	D	200	6.000
70	7.000	E	250	7.000
80	8.000	F	300	8.000
90	5.500	G	350	5.500
100	5.625	H	400	3.500
110	5.300	J	450	3.500
125	14.000	K	500	3.750
140	6.800	L	Special version	
150	4.400	M	X	






OAL



**4 Clearance angle**

	$\alpha$	$\alpha$	
A	3°	F	25°
B	5°	G	30°
C	7°	N	0°
D	15°	P	11°
E	20°		

**O** Clearance angles not included within the standard for which particular information is necessary.



## ISO designation system for boring bars

A 25 R      P C L N R      12

1	2	3		
4	5	6	7	8
9	10			

UT40 - 25 G - P C L N R - 12

0				
1	2	3		
4	5	6	7	8
9	10			


HSK-T63 - 50 Q - D C L N R - 12

0				
1	2	3		
4	5	6	7	8
9	10			

0	System/size
	<b>UT</b> = UTS
	according to ISO 26622
	UT40 = UTS 40 mm
	UT50 = UTS 50 mm
	UT63 = UTS 63 mm
	<b>HSK-T</b>
	according to ISO 12164
	HSK-T63 = 63 mm
	HSK-T100 = 100 mm

1	Shank type
S	Steel shank
E	As C with coolant hole
A	Steel shank with coolant hole
F	As C with antivibration system
B	Steel shank with antivibration system
G	As C with coolant hole and antivibration system
D	Steel shank with coolant hole and antivibration system
H	Heavy metal
C	Carbide shank with steel head
J	Heavy metal with coolant hole

5	Insert shape
V	35° Included angle
D	55°
E	75°
C	80°
M	86°
K	55° Included angle
B	82°
A	85°
L	90°
P	108°
H	120°
O	135°
R	-
S	90°
T	60°
W	80°
	Other shapes



7	Clearance angle
A	3°
B	5°
C	7°
D	15°
E	20°
F	25°
G	30°
N	0°
P	11°
O	Clearance angles not included within the standard for which particular information is necessary.



**2**

Shank type & size

DCONMS mm	DCONMS inch
08	
10	
12	
16	
20	
25	
32	
40	
50	
60	

A two-digit figure indicating the boring bar diameter in 1/16 of an inch.

**3**




Tool length

OAL		
mm	inch	
80	3	F
100	3,5	H
110	4	J
125	4,5	K
140	5	L
150	5,5	M
160	6	N
170	6,5	P
180	6,75	Q
200	7	R
250	8	S
300	10	T
350	12	U
400	14	V
450	16	W
500	18	Y
	20	
Special version		X

**4**

Clamping method

D		S	
Retained from above and via bore		Retained via centre screw	
M		P	
Retained from above and via bore		Retained via the bore	
C		X	Special version
Retained from above			



## Types of wear

PCBN indexable inserts can be easily damaged if used incorrectly, or can even break. Frequent application errors include selecting the incorrect cutting material grade, incorrect cutting parameters (feed and cutting speed), and incorrect cutting edge preparation. In addition, unstable tools with a large overhang length and poor workpiece clamping can cause vibrations during hard turning.

### Wear on clearance face



#### Cause

Abrasion on the flank: normal wear after a certain period of operation.

#### Remedy

- ▲ Reduction of cutting speed
- ▲ Increase feed (reduction of reaming length)
- ▲ Use more wear-resistant grade
- ▲ Reduce chamfer angle
- ▲ Use air cooling
- ▲ Use positive clearance angle

### Edge breakages



#### Cause

Increased mechanical stress on the cutting edge results in chipping.

#### Remedy

- ▲ Use grade with higher PCBN content
- ▲ Reduction of cutting speed
- ▲ Increase chamfer angle and width
- ▲ Check centre height
- ▲ Reduce the feed
- ▲ Use larger corner radius
- ▲ Reduce vibrations
- ▲ Improve stability (tool, workpiece)

### Cratering



#### Cause

The outgoing hot chip is causing cratering of the cutting insert on the clamping flat.

#### Remedy

- ▲ Use crater-resistant grades
- ▲ Reduction of cutting speed
- ▲ Increase the feed, thus reducing the reaming length
- ▲ Reduce chamfer angle

### Notch wear



#### Cause

Necking at the maximum depth of cut.

#### Remedy

- ▲ Use grade with higher PCBN content
- ▲ Increase the cutting speed
- ▲ Reduce the feed
- ▲ Vary cutting depth
- ▲ Reduce chip thickness
- ▲ Increase corner radius (this reduces the setting angle)

### Insert breakage



#### Cause

If a cutting insert is overloaded, insert breakage may occur.

#### Remedy

- ▲ Use a tougher cutting material
- ▲ Reduction of cutting speed
- ▲ Increase chamfer angle and width
- ▲ Reduce the feed
- ▲ Use larger corner radius
- ▲ Reduce vibrations
- ▲ Improve stability (tool, workpiece)
- ▲ Use more stable geometry
- ▲ Reduce cutting depth
- ▲ Check interference contours

# Troubleshooting guide for turning

## Problem

Type of wear	Workpiece problems							Remedy measures
Wear on clearance face								
Cratering	↓	↓		↓	↑	↓		Cutting speed $v_c$
Notch wear	↑	↑	↓	↓	↓	↔	↑	Feed $f$
Cracks at right angles to the cutting edge	↑	↑	↓	↓	↑	↓	↑	Depth of cut $a_p$
Edge chipping								
Insert breakage								
Chipping on the surface								
Surface quality								
Vibration								
Burr formation								
Chamfer angle 35°, heavily interrupted cut								
Chamfer angle 25°, continuous, slightly interrupted cut								
Chamfer angle 15°, continuous, slightly interrupted cut								
Corner radius								larger ↑ ↓ smaller
Rounding								
BH								Wear resistance ↑ ↓
PCBN content								
BL								toughness ↑ ↓
Tool clamping								
Work piece clamping								
Overhang								
Tip height								
Cooling lubricant								
↑ raise, increase, large influence	↓ avoid, reduce, large influence	↔ check, optimise						
↑ raise, increase, small influence	↓ avoid, reduce, small influence	● use	○ do not use					

## Measures in the case of turning problems with PCBN

### Troubleshooting

Problem	Possible causes	Remedy
Poor tool lives	<ul style="list-style-type: none"> <li>▲ Cutting speed not within the specifications</li> <li>▲ Chip softening not carried out</li> </ul>	<ul style="list-style-type: none"> <li>▲ Increase the cutting speed</li> <li>▲ Ideally, chip is red hot</li> </ul>
Bad surface quality	<ul style="list-style-type: none"> <li>▲ Feed too high</li> <li>▲ Corner radius too small</li> </ul>	<ul style="list-style-type: none"> <li>▲ Reduce feed</li> <li>▲ Increase corner radius</li> </ul>
Chatter marks	<ul style="list-style-type: none"> <li>▲ Tool overhang too long</li> </ul>	<ul style="list-style-type: none"> <li>▲ Reduce projection length</li> <li>▲ Use more stable holder</li> </ul>
Vibration	<ul style="list-style-type: none"> <li>▲ Cutting pressure too high</li> <li>▲ Chip thickness too large</li> <li>▲ Centre height incorrect</li> <li>▲ Unstable tool or workpiece clamping</li> <li>▲ Indexable insert radius too large, high recoil force</li> </ul>	<ul style="list-style-type: none"> <li>▲ Reduce cutting pressure</li> <li>▲ Reduce chip thickness</li> <li>▲ Check/adjust centre height</li> <li>▲ Use smaller radius</li> </ul>
Burrs on workpiece	<ul style="list-style-type: none"> <li>▲ With soft materials (sintered steel)</li> <li>▲ Cutting pressure too high</li> <li>▲ Corner radius too large</li> <li>▲ Chamfer angle too large</li> </ul>	<ul style="list-style-type: none"> <li>▲ Use smaller radius</li> <li>▲ Adjust chip thickness</li> <li>▲ Increase cutting depth</li> <li>▲ Increase cutting speed</li> <li>▲ Reduce chamfer angle</li> <li>▲ Use sharp cutting edge</li> </ul>
Notch wear	<ul style="list-style-type: none"> <li>▲ Constant cutting depth leaving witness</li> </ul>	<ul style="list-style-type: none"> <li>▲ For dual-cut strategy, use different cutting depths</li> <li>▲ Increase chamfer angle</li> </ul>
Edge breakage on the workpiece	<ul style="list-style-type: none"> <li>▲ Sharp edge at the exit</li> </ul>	<ul style="list-style-type: none"> <li>▲ Change machining direction</li> <li>▲ Reduce feed at entry and exit</li> <li>▲ Program soft machining with chamfers and radii</li> </ul>

## General formulae

### Cutting speed [m/min]

$$V_c = \frac{d \cdot \pi \cdot n}{1000}$$

### Speed [rpm]

$$n = \frac{V_c \cdot 1000}{\pi \cdot d}$$

### Feed [mm/rev]

$$f = \frac{V_f}{n}$$

### Clamping cross-section [mm<sup>2</sup>]

$$A = a_p \cdot f$$

### Feed rate [mm/min]

$$V_f = f \cdot n \quad [\text{mm/min}]$$

### Chip volume [cm<sup>3</sup>/min]

$$Q = V_c \cdot A \cdot f \quad [\text{cm}^3/\text{min}]$$

### Cutting length [m]

$$SCL = \frac{d \cdot 3,14 \cdot l_m}{1000 \cdot f_n}$$

### Chip thickness

$$h = f \cdot \sin x$$

### Period of operation [min]

$$T_c = \frac{l_m}{f \cdot n}$$

## KEY

$V_c$	= Cutting speed [m/min]
$d$	= Turning diameter [mm]
$n$	= Speed [rpm]
$\pi$	= 3.141592
$f$	= Feed [mm/rev]
$V_f$	= Feed rate [mm/min]
$A$	= Clamping cross-section [mm <sup>2</sup> ]
$a_p$	= Depth of cut [mm]
$z$	= Number of flutes
$Q$	= Chip volume [cm <sup>3</sup> /min]

$SCL$	= Cutting length [m]
$l_m$	= Turning length [mm]
$T_c$	= Period of operation [min]
$h$	= Chip thickness
$\sin x$	= Approach angle

## Hardness comparison table

Tensile strength N/mm	Vickers HV	Brinell HB	Rockwell HRC	Shore C
575	180	171		
595	185	176		
610	190	181		
625	195	185		
640	200	190	12	
660	205	195	13	
675	210	199	14	
690	215	204	15	
705	220	209	15	28
720	225	214	16	
740	230	219	17	29
755	235	223	18	
770	240	228	20.3	30
785	245	233	21.3	
800	250	238	22.2	31
820	255	242	23.1	32
835	260	247	24	33
850	265	252	24.8	
865	270	257	25.6	
880	275	261	26.4	34
900	280	268	27.1	
915	285	271	27.8	35
930	290	276	28.5	
950	295	280	29.2	36
965	300	285	29.8	37
995	310	295	31	38
1030	320	304	32.2	39
1060	330	314	33.3	40
1095	340	323	34.3	41
1125	350	333	35.5	42
1155	360	342	36.6	43
1190	370	352	37.7	44
1220	380	361	38.8	45
1255	390	371	39.8	46
1290	400	380	40.8	47
1320	410	390	41.8	48
1350	420	399	42.7	
1385	430	409	43.6	49
1420	440	418	44.5	
1455	450	428	45.3	51
1485	460	437	46.1	52
1520	470	447	46.9	53
1555	480	465	47.7	54
1595	490	466	48.4	
1630	500	475	49.1	57
1665	510	485	49.8	58
1700	520	494	50.5	59
1740	530	504	51.1	60
1775	540	513	51.7	61
1810	550	523	52.3	62

Tensile strength N/mm	Vickers HV	Brinell HB	Rockwell HRC	Shore C
1845	560	532	53	63
1880	570	542	53.6	64
1920	580	551	54.1	65
1955	590	561	54.7	66
1995	600	570	55.2	67
2030	610	580	55.7	68
2070	620	589	56.3	69
2105	630	599	56.8	70
2145	640	608	57.3	71
2180	650	618	57.8	72
2210	660	628	58.3	73
2240	665	633	58.8	74
2280	670	638	59.3	
2310	675	643	59.8	75
2350	680	648	60.3	76
2380	685	653	61.1	77
2410	690	658	61.3	78
2450	695	663	61.7	79
2480	710	668	62.2	80
2520	720	678	62.6	81
2550	730	683	63.1	82
2590	740	693	63.5	
2630	750	703	63.9	83
2660	760	708	64.3	84
2700	770	718	64.7	85
2730	780	723	65.1	
2770	790	733	65.5	86
2800	800	738	65.9	
2840	810	748	66.3	87
2870	820	753	66.7	88
2910	830	763	67	
2940	840	768	67.4	89
2980	850		67.7	
3010	860		68.1	90
3050	870		68.4	
3080	880		68.7	91
3120	890		69	
3150	900		69.3	92
3190	910		69.6	
3220	920		69.9	
3260	930		70.1	

Conversion values are approximate, based on DIN EN ISO18265 (02-2004)

# Extended Material Examples for the Cutting Data Tables

	Material sub-group	Index	Composition / Structure / Heat treatment		Tensile strength N/mm <sup>2</sup> / HB / HRC
P	Unalloyed steel	P.1.1	< 0,15 % C	Annealed	420 N/mm <sup>2</sup> / 125 HB
		P.1.2	< 0,45 % C	Annealed	640 N/mm <sup>2</sup> / 190 HB
		P.1.3		Tempered	840 N/mm <sup>2</sup> / 250 HB
		P.1.4	< 0,75 % C	Annealed	910 N/mm <sup>2</sup> / 270 HB
		P.1.5		Tempered	1010 N/mm <sup>2</sup> / 300 HB
	Low-alloy steel	P.2.1		Annealed	610 N/mm <sup>2</sup> / 180 HB
		P.2.2		Tempered	930 N/mm <sup>2</sup> / 275 HB
		P.2.3		Tempered	1010 N/mm <sup>2</sup> / 300 HB
		P.2.4		Tempered	1200 N/mm <sup>2</sup> / 375 HB
	High-alloy steel and high-alloy tool steel	P.3.1		Annealed	680 N/mm <sup>2</sup> / 200 HB
		P.3.2		Hardened and tempered	1100 N/mm <sup>2</sup> / 300 HB
		P.3.3		Hardened and tempered	1300 N/mm <sup>2</sup> / 400 HB
	Stainless steel	P.4.1	Ferritic / martensitic	Annealed	680 N/mm <sup>2</sup> / 200 HB
		P.4.2	Martensitic	Tempered	1010 N/mm <sup>2</sup> / 300 HB
M	Stainless steel	M.1.1	Austenitic / austenitic-ferritic	Quenched	610 N/mm <sup>2</sup> / 180 HB
		M.2.1	Austenitic	Tempered	300 HB
		M.3.1	Austenitic / ferritic (Duplex)		780 N/mm <sup>2</sup> / 230 HB
K	Grey cast iron	K.1.1	Pearlitic / ferritic		350 N/mm <sup>2</sup> / 180 HB
		K.1.2	Pearlitic (martensitic)		500 N/mm <sup>2</sup> / 260 HB
	Spherulitic graphite cast iron	K.2.1	Ferritic		540 N/mm <sup>2</sup> / 160 HB
		K.2.2	Pearlitic		845 N/mm <sup>2</sup> / 250 HB
	Malleable iron	K.3.1	Ferritic		440 N/mm <sup>2</sup> / 130 HB
		K.3.2	Pearlitic		780 N/mm <sup>2</sup> / 230 HB
N	Aluminium wrought alloy	N.1.1	Non-hardenable		60 HB
		N.1.2	Hardenable	Age-hardened	340 N/mm <sup>2</sup> / 100 HB
	Cast aluminium alloy	N.2.1	≤ 12 % Si, non-hardenable		250 N/mm <sup>2</sup> / 75 HB
		N.2.2	≤ 12 % Si, hardenable	Age-hardened	300 N/mm <sup>2</sup> / 90 HB
		N.2.3	> 12 % Si, non-hardenable		440 N/mm <sup>2</sup> / 130 HB
	Copper and copper alloys (bronze/brass)	N.3.1	Free-machining alloys, PB > 1 %		375 N/mm <sup>2</sup> / 110 HB
		N.3.2	CuZn, CuSnZn		300 N/mm <sup>2</sup> / 90 HB
		N.3.3	CuSn, lead-free copper and electrolytic copper		340 N/mm <sup>2</sup> / 100 HB
	Magnesium alloys	N.4.1	Magnesium and magnesium alloys		70 HB
S	Heat-resistant alloys	S.1.1	Fe - basis	Annealed	680 N/mm <sup>2</sup> / 200 HB
		S.1.2		Age-hardened	950 N/mm <sup>2</sup> / 280 HB
		S.2.1		Annealed	840 N/mm <sup>2</sup> / 250 HB
		S.2.2	Ni or Co basis	Age-hardened	1180 N/mm <sup>2</sup> / 350 HB
		S.2.3		Cast	1080 N/mm <sup>2</sup> / 320 HB
	Titanium alloys	S.3.1	Pure titanium		400 N/mm <sup>2</sup>
		S.3.2	Alpha + beta alloys	Age-hardened	1050 N/mm <sup>2</sup> / 320 HB
		S.3.3	Beta alloys		1400 N/mm <sup>2</sup> / 410 HB
H	Hardened steel	H.1.1		Hardened and tempered	46–55 HRC
		H.1.2		Hardened and tempered	56–60 HRC
		H.1.3		Hardened and tempered	61–65 HRC
		H.1.4		Hardened and tempered	66–70 HRC
	Chilled iron	H.2.1		Cast	400 HB
O	Hardened cast iron	H.3.1		Hardened and tempered	55 HRC
	Non-metal materials	O.1.1	Plastics, duroplastic		≤ 150 N/mm <sup>2</sup>
		O.1.2	Plastics, thermoplastic		≤ 100 N/mm <sup>2</sup>
		O.2.1	Aramid fibre-reinforced		≤ 1000 N/mm <sup>2</sup>
		O.2.2	Glass/carbon-fibre reinforced		≤ 1000 N/mm <sup>2</sup>
		O.3.1	Graphite		

\* Tensile strength

The pages that follow give further information on our material examples for our usual indexes with additional international standards.

## Overview of standards:

### DIN

Deutsche Industrie Norm (German Standard)

### AFNOR

Association Francaise de Normalisation (French Standard)

### UNI

Unificazione Italiana (Italian Standard)

### ČSN

Czechoslovakian Standard

### BS

British Standards

### SIS

Standardiseringen i Sverige (Swedish Standard)

### UNE

Spanish Standard

### JIS

Japanese Industrial Standard

### ГОСТ

Soviet Standard

### UNS

Unified Numbering System


### USA

Under USA several American standards are summarized

## Extract H materials:

	Index	Material number	DIN	AFNOR	UNI	ČSN	BS	SIS	UNE	JIS	FOCT	UNS	USA
H.1.1	1.2311	40 CrMnMo 7				19 520							
	1.2312	40 CrMnMoS 8 6	40 CMD 8 + S										
	1.2316	X 36 CrMo 17	Z 38 CD 17	X 38 CrMo 16 1 KU									
	1.2365	X 32 CrMoV 3 3	32 DCV 28	30 CrMoV 12 27 KU	19 541	BH 10				SKD 7	3Ch3M3F	T 20810	H 10
	1.2567	X 30 WCrV 5 3	Z 32 WCV 5	X 30 WCrV 5 3 KU	19 720					SKD 4			
	1.2581	X 30 WCrV 9 3	Z 30 WCV 9	X 30 WCrV 9 3 KU	19 721	BH 21				SKD 5	3Ch2W8F	T 20821	H 21
	1.2738	40 CrMnNiMo 8						F-5303					
	1.2885	X 32 CrMoCoV 3 3 3	30 DCKV 28										
	1.4028	X 30 Cr 13	Z 30 C 13	X 30 Cr 13	17 023	420 S 45	2304		SUS 420 J 2	30Ch13			
	1.4031	X 38 Cr 13	Z 40 C 14	X 40 Cr 14	17 024		2304	F-3404	SUS 420 J 2	40Ch13			
	1.4034	X 46 Cr 13	Z 40 C 14	X 40 Cr 14	17 029	420 S 45		F-3405		40Ch13			
	1.4112	X 90 CrMoV 18										S 44003	
	1.5122	37 MnSi 4				13 240							
	1.6358	X 2 NiCoMoTi 18 9 5											
	1.6582	34 CrNiMo 6	35 NCD 6	35 NiCrMo 6 (KW)	16 342	817 M 40	2541	F-128 / F-1270	SNCM 447	38Ch2N2MA			4340
	1.7003	38 Cr 2	38 C 2	38 Cr 2									
	1.7006	46 Cr 2	42 C 2	45 Cr 2									5045
	1.7030	28 Cr 4				530 A 30				30Ch			5130
	1.7176	55 Cr 3	55 C 3	55 Cr 3		527 A 60	2253	F-1431	SUP 9 (A)	50ChGA	G 51550		5155
	1.0961	60 SiCr 7	60 SC 7	60 SiCr 8					SUP 7				9262
	1.1248	Ck 75	XC 75	C 75	12 081	060 A 78	1774; 1778				75	G 10780	1078; 1080
	1.1273	90 Mn 4											
H.1.2	1.2083	X 42 Cr 13	Z 40 C 14	X 41 Cr 13 KU	19 435			F-5263	SUS 420 J 2				
	1.2323	GS-48 CrMoV 6 7											
	1.2343	X 38 CrMoV 5 1	Z 38 CDV 5	X 37 CrMoV 5 1 KU	19 552	BH 11		F-5317	SKD 6	4Ch5MFS	T 28811		H 11
	1.2367	X 38 CrMoV 5 3											
	1.2510	100 MnCrW 4	90 MWCV 5	95 MnWCr 5 KU	19 314	BO 1	2140	F-5220	SKS 3		T 31501	O 1	
	1.2542	45 WCrV 7		45 WCrV 8 KU	19 732	BS 1	2710				T 41901	S 1	
	1.2550	60 WCrV 7	55 WC 20	55 WCrV 8 KU	19 735								
	1.2606	G-X 37 CrMoW 5 1											
	1.2711	54 NiCrMoV 6	55 NCDV 6		19 662								
	1.2713	55 NiCrMoV 6	55 NCDV 7		19 662			F-520.S	SKT 4	5ChNM	T 61206	L 6	
	1.2764	X 19 NiCrMo 4											
	1.2767	X 45 NiCrMo 4	Y 35 NCD 16	42 NiCrMo 15 7	19 655								
	1.4109	X 65 CrMo 14											
H.1.3	1.4112	X 90 CrMoV 18									S 44003		
	1.1157	40 Mn 4	35 M 5			150 M 36				40G	G 10390	1039	
	1.1231	Ck 67	XC 68	C 70	12 071	060 A 67	1770			70	G 10700	1070	
	1.1274	Ck 101	XC 100			060 A 96	1870		SUP 4		G 10950	1095	
	1.2080	X 210 Cr 12	Z 200 C 12	X 210 Cr 13 KU	19 436	BD 3			SKD 1	Ch12	T 30403	D 3	
	1.2101	62 SiMnCr 4											
	1.2162	21 MnCr 5	20 NC 5		19 487				SCR 420 H				
	1.2201	G-X 165 CrV 12											
	1.2210	115 CrV 3	100 C 3	107 CrV 3 KU	19 421						T 61202	L 2	
	1.2341	X 6 CrMo 4											
H.2.1	1.2379	X 155 CrVmO 12 1	Z 160 CDV 12	X 155 CrVmO 12 1 KU	19 573	BD 2		F-5211	SKD 11		T 30402	D 2	
	1.2419	105 WCr 6	105 WC 13	107 WCr 5 KU					SKS 31	ChWG			
	1.2601	X 165 CrMoV 12		X 165 CrMoW 12 KU	19 572		2310						

	Index	Material number	DIN	AFNOR	UNI	ČSN	BS	SIS	UNE	JIS	FOCT	UNS	USA
H.1.3	1.2721	50 NiCr 13											
	1.2735	15 NiCr 14	10 NC 12			16 240				SNC 22		T 51606	
	1.2833	100 V 1	Y1 105 V	102 V 2 KU	19 356	BW 2				SKS 43		T 72302	W 210
	1.2842	90 MnCrV 8	90 MV 8	90 MnCrV 8 KU	19 314	BO 2						T 31502	O 2
	1.3505	100 Cr 6	100 C 6	100 Cr 6	14 100	534 A 99	2258	F-131 / F-1310	SUJ 2	SchCh 15	G 52986	52100	
	1.4112	X 90 CrMoV 18										S 44003	
	1.4125	X 105 CrMo 17	Z 100 CD 17	X 105 CrMo 17					SUS 440 C			S 44004	440 C
	1.8161	58 CrV 4				15 261							
	1.1520	C 70 W1											
H.1.4	1.2363	X 100 CrMoV 5 1	Z 100 CDV 5	X 100 CrMoV 5 1 KU	19 571	BA 2	2260	F-5227	SKD 12			T 30102	A 2
	1.2436	X 210 CrW 12	Z 200 CW 12	X 215 CrW 12 1 KU	19 437		2312	F-5213	SKD 2				
	1.2880	G-X 165 CrCoMo 12											
	1.3202	S 12-1-4-5			19 858							T 12015	T15
	1.3207	S 10-4-3-10	Z 130 WKCDV 10-10-04	HS 10-4-3-10	19 861	BT 42		F-5553	SKH 57				
	1.3243	S 6-5-2-5	Z 85 WDKCV 06-05-05	HS 6-5-2-5	19 852		2723	F-5613	SKH 55	R6M5K5			
	1.3246	S 7-4-2-5	Z 110 WKCDV 07-05-04	HS 7-4-2-5	19 851							T 11341	M 41
	1.3247	S 2-10-1-8	Z 110 DKCWV 09-08-04	HS 2-9-1-8		BM 42			SKH 51			T 11342	M 42
	1.3249	S 2-9-2-8				BM 34						T 11333	M 33; M 34
	1.3257	S 18-1-2-15											
	1.3333	S 3-3-2		HS 3-3-2	19 820								
	1.3343	S 6-5-2	Z 85 WDCV 06-05-04-0	HS 6-5-2	19 830	BM 2	2722	F-5603	SKH 9; SKH 51	R6AM5	T 11302	M 2	
	1.3344	S 6-5-3	Z 120 WDCV 06-05-04	HS 6-5-3		BM 4			SKH 52; SKH 53		T 11323	M 3 Cl. 2	
	1.3346	S 2-9-1	Z 85 DCWV 08-04-02-0	HS 1-8-1		BM 1				H41	T 11301	H 41; M 1	
	1.3348	S 2-9-2	Z 100 DCWV 09-04-02	HS 2-9-2			2782				T 11307	M 7	
	1.3355	S 18-0-1	Z 80 WCV 18-04-01	HS 18-0-1	19 824	BT 1			SKH 2	R18	T 12001	T 1	
	1.1654	C 110 W											
H.3.1	0.9620	G-X 260 NiCr 4 2				Grade 2 A	0512-00						A 532 I B NiCr-LC
	0.9625	G-X 330 NiCr 4 2				Grade 2 B	0513-00						A 532 I A NiCr-HC
	0.9630	G-X 300 CrNiSi 9 5 2				Grade 2 C; D; E	0457-00						A 532 I D Ni-HiCr
	0.9635	G-X 330 CrMo 15 3				Grade 3 A; B							A 532 II C 15% CrMo-
	0.9640	G-X 300 CrMoNi 15 2				Grade 3 A; B							A 532 II D 20% CrMo-
	0.9645	G-X 260 CrMoNi 20 2				Grade 3 C							A 532 III A 25% Cr
	0.9650	G-X 260 Cr 27				Grade 3 D	0466-00						A 532 III A 25% Cr
	0.9655	G-X 300 CrMo 27 1				Grade 3 E							



**From consulting to  
successful completion, we  
realise your application-specific  
project goals**

# Developing optimal processes

**Benefit from our innovative tool concepts, many years of experience and professional advice to increase your productivity**

In order to machine increasingly complex workpieces cost effectively and to a high level of quality, all the process parameters need to be tailored to the specific task. Those who succeed in meeting these challenges will remain competitive on the global market. However, the reality is that businesses often do not have the capacity to analyse manufacturing processes and optimise them to make them more efficient. There is also usually not enough time to tailor new cutting materials, tool geometries or process technologies to the individual machining operations. This is precisely where our project engineering comes in. As one of the leading tool manufacturers and innovators in the machining industry, we develop ideal tool concepts for you based on key success factors such as efficiency, time and quality. Why are we the ideal system partner for you? We have many years of experience in the development of innovative tool solutions, can draw on sound technical expertise and provide first-rate service. What's more, with our leading product brands Cutting Solutions by CERATIZIT, KOMET, WNT and KLENK, we are a full-service provider in machining, offering one of the most comprehensive ranges of cutting tools and services. If you want to set the pace rather than risk falling behind the international competition, then get in touch with us now!


**You can rely on us to implement your project successfully!**



## Project consulting



## Project development & quotation



## Project implementation



## Ongoing support



---

**We always keep your objectives in mind**  
and provide you with advice across all industries in all application ranges. Benefit from our many years of experience and our innovative solutions.

The services we provide

- ▲ Consulting service for all applications and industries
- ▲ Needs-oriented advice on process optimisation
- ▲ Dedicated project manager

---

**Our interdisciplinary project team**  
develops the ideal machining concept for your individual specifications and objectives using high-end CERATIZIT tools.

The services we provide

- ▲ Development of a machining and tool concept
- ▲ Cycle time consideration
- ▲ Machining tests in our in-house Technical Centers
- ▲ Prognosis of the tooling requirement and tool costs per component
- ▲ Business quotation

---

**Our expert team**  
implements the concept on your machine, working closely with you and your dedicated CERATIZIT application engineer. This on-site support guarantees you will receive a stable and cost-effective manufacturing process for your product.

The services we provide

- ▲ Detailed planning of the machining process
- ▲ Tool design
- ▲ Collision monitoring
- ▲ Tool assembly
- ▲ Support from a dedicated application engineer when proving out the machining process and for CNC programming
- ▲ Tool documentation
- ▲ Regular project status reports

---

**Even after successful implementation**  
of the project, we are here for you. Your dedicated application engineer keeps an eye on your manufacturing processes, determines further potential for optimisation and provides you with ongoing support for all the challenges you face.

The services we provide

- ▲ Ongoing manufacturing support
- ▲ Series production support and process optimisation



Our current valid terms and conditions apply which can be found on our website. Images and prices are valid, subject to corrections due to technical improvements or further developments as well as general mistakes and typographical errors.



**COMPLEX COMPONENTS.  
PRECISION METAL CUTTING.**

**JUST  
OUR  
THING**



**ADVANCING METAL CUTTING.  
WITH STRAIGHTFORWARD AND HELPFUL ADVICE.**

**SMALL ORDER QUANTITY.  
ON THE ROAD IMMEDIATELY.**

[www.just-our-thing.com](http://www.just-our-thing.com)



**THE Cutting Tool Solution**

